KNUCKLE JOE by **Seibu Kaihatsu**

PART SIDE			SOLDER SIDE
GND	1	A	GND
+5V	2	B	+5V
+5V	3	C	+5V
Coin 1	4	D	Coin 2
1P.Left	5	E	1P.Right
2P.Left	6	F	2P.Right
	7	G	Blue
Green	8	H	Red
2P.Kick	9	I	1P.Kick
Speaker	10	J	Speaker
+12V	11	K	+12V
+12V	12	L	+12V
Sync	13	M	
1P.Punch	14	N	2P.Punch
1P.Start	15	O	2P.Start
	16	P	
2P.Up	17	Q	1P.Up
2P.Down	18	R	1P.Down
Counter	19	S	Counter
	20	T	
GND	21	U	GND
GND	22	V	GND